

- 1. Clamp one end of the red cable (+) to the positive (+) terminal on the battery of the DEAD car. If there is a cover on it, take that off first.
- 2. Clamp the other end of the red cable (+) to the positive (+) terminal but this time on the battery of the BOOST car.
- 3. Clamp one end of the black cable (-) to the negative (-) terminal on the battery of the BOOST car. If there is a cover on it, take that off first.
- 4. Clamp the other end of the black cable (-) to the some unpainted metal screw or knob near the battery of the DEAD car. This is to ground the connection. Do not connect it to the negative (-) of the BOOST car's battery or have it touch the engine.

Now that that's done, you can start the BOOST car. Let it run for a few minutes so the power juice starts flowing. Next, start the DEAD car and let that run for a few minutes as well. When done, remove cables in <u>reverse</u> order of how you put them on (step 4, then step 3, and so on).